



Model 105

Listed Dimensions:

24" L x 12" W x 12" H





IDEAL CONCEALING APPLICATIONS:

- -Feature Rock with Optional Address Plaque
- -Municipal Water Supply Curb Stops
- -Outdoor Ground Fault Electrical Outlets
- -Septic / Sewer Cleanouts

Sample Interior Spacing

Height	Length	Width
2"	18"	4"
6"	14"	3"
10"	7"	2"

Diameter Sizing

Height	Diameter	
2"	10" Dia	
6"	6" Dia	
10"	3" Dia	

ENCLOSURE FEATURES AND BENEFITS:

- -Realrock™ material provides the realistic rock features
- -Commercial grade construction stands up to elements
- -Lightweight, easy to move and incredible durable
- -Rocks will not fade in sun or crack in cold weather
- -Rocks designed to conceal existing utility devices






Model 106

Listed Dimensions:

19" L x 14" W x 12" H





IDEAL CONCEALING APPLICATIONS:

- -Residential Electrical Pedestals
- -Municipal Water Supply Curb Stops
- -Outdoor Ground Fault Electrical Outlets
- -Septic / Sewer Cleanouts

Sample Interior Spacing

Height	Length	Width
2"	11"	10"
6"	12"	4"
10"	8"	3"

Diameter Sizing

Height	Diameter	
2"	11" Dia	
6"	9" Dia	
9"	7" Dia	

ENCLOSURE FEATURES AND BENEFITS:

- -Realrock™ material provides the realistic rock features
- -Commercial grade construction stands up to elements
- -Lightweight, easy to move and incredible durable
- -Rocks will not fade in sun or crack in cold weather
- -Rocks designed to conceal existing utility devices















INSTALLATION INSTRUCTIONS:


- If heat is required, installations will require GFI protected power mounted at least 6" above all water discharge ports or per local code regulations.
- If concrete base is required. Pour concrete pad per measurements provided. If mounting to ground, level area where enclosure is to be installed.
- If installation requires self regulated heat tape, install per instructions securing to piping and valve. Place insulated pouch over valve and piping assembly.
- Place rock over device. Verify that rock does not interfere
 with device. Insert included stakes for soil installation. For
 concrete installations see optional concrete installation instructions.

CONCRETE ANCHOR INSTALLATIONS

- Drill hole with same diameter as anchor of sufficient depth. Clean drilled hole of dust and debris.
- Place washer and nut onto threaded anchor as required.
- With nut, washer and set pin in place insert anchor through rock flange column and into concrete base.
- Using a proper size hammer set pin with several sharp and square strikes on head of pin until pin is flush with top of threaded anchor.











3 Fairfield Boulevard, Wallingford, Connecticut 06492 Office: 1-877-765-9565 Fax: 203-284-8514 email: sales@polylok.com

Web site: www.polylok.com